



# CHEVROLET CAPTIVA

## DOGBARRIER Art.nr. 40406



### **ASSEMBLY INSTRUCTIONS:**

- Place the barrier in place, resting against the C-bars of the car.
- Latch on the hooks into the panel of the seatbelt and put the threaded end through the sockets of the barrier.
- Fastened with the knobs.

### **MONTERINGSDETALJER:**

Name	Amount
• Knob M8	2
• Threaded hook nr:22	2

