

**MONTERINGSANVISNING:**

- Position the barrier resting on the C-bars of the car.  
Hook the hooks in the gap where the carseat exits, put threaded ends through the sockets of the barrier
- Fastened with the wheelnuts.

**MOUNTINGHARDWARE:**

- Hook nr:22                   2
- Wheelnut M8                 2

